

SmartSense Glycol Probe Installation Guide

SMART SENSE

BY DIGI[®]

Note: You must update *all* glycol probes on all active Z Sensors

What You Will Need:



Glycol Probe(s)
(Automatically ordered for your store)



Z Sensor(s)
(Already installed in store)

Instructions:

1. To connect a new glycol probe, first unscrew the existing probe, counterclockwise, from Port 1 on the Z Sensor and safely discard.
2. Line up the arrow on Port 1 with the arrow on the glycol probe's connector. There are five pins on the Z Sensor that correspond with the five holes on the glycol probe's connector.
3. Carefully screw in the glycol probe in a clockwise direction. **DO NOT USE EXCESSIVE FORCE**, as this can damage the pins.
4. Place the Z Sensor inside your fridge or freezer, near the rear of the unit. Carefully lay the glycol probe on the shelf of the fridge or freezer.
5. Log in to app.smartsense.co to verify the Z Sensor is reporting temperature readings.
6. The updated calibration certificate will appear within 72 hours of installation.

