

SmartSense Glycol Probe Installation Guide

SMART SENSE

BY DIGI[®]

Note: You must update *all* glycol probes on all active Z Sensors

What You Will Need:



Glycol Probe(s)
SKU (stock keeping unit): NIST-TMP5PINDIN-BUFF12
(Automatically ordered for your store)



Z Sensor(s)
SKU: TM-ZP300-DS / TM-ZP300-S
(Already installed in store)

Instructions:

1. To connect a new glycol probe, first unscrew the existing probe, counterclockwise, from Port 1 on the Z Sensor and safely discard. **DO NOT USE HAND TOOLS AND ONLY REPLACE BY HAND.**
2. Line up the arrow on Port 1 with the arrow on the glycol probe's connector. There are five pins on the Z Sensor that correspond with the five holes on the glycol probe's connector.
3. Carefully screw in the glycol probe in a clockwise direction. **DO NOT USE EXCESSIVE FORCE**, as this can damage the pins.
4. Place the Z Sensor **BACK** inside your fridge or freezer **ASSET**, near the rear of the unit. Carefully lay the glycol probe on the shelf of the fridge or freezer.
5. Log in to app.smartsense.co to verify the Z Sensor is reporting temperature readings.
6. The updated calibration certificate will appear within 24 hours of installation.

